# Session 6. (1:15) EIA Skills Part II & Downstream Compliance: Environmental Monitoring, EMMPs and Reporting

# **Objectives**

Establish the objective of environmental monitoring (determining clearly and cost-effectively if mitigation is sufficient and effective); brief the two types of <u>environmental</u> monitoring indicators; and achieve a common understanding of the principles of <u>environmental</u> monitoring design.

Brief the EMMP concept; establish that EMMPs are critical to effective and systematic implementation of IEE/EA conditions; explain the mechanisms by which USAID is requiring IPs to develop and implement EMMPs.

Practice translating general IEE conditions into specific mitigation actions.

Achieve a common understanding of the two basic elements of IP environmental compliance reporting: (1) providing USAID with an auditable record of IP environmental compliance; and (2) "mainstreaming" critical elements of environmental soundness/compliance into one or more core program performance indicators.

Understand the relationship between the EMMP and IP environmental compliance reporting.

#### **Format**

Presentation & Q&A (1:00); short group discussion/exercise (0:15)

#### Summary

This session continues our acquisition of core EIA skills critical to life-of-project compliance. It has four major parts:

- 1. Principles of Environmental Monitoring,
- 2. Environmental Mitigation and Monitoring Plans,
- 3. Translating general IEE or EA conditions to mitigation actions.
- 4. EMMP-based environmental compliance reporting.

#### Part 1. Environmental Monitoring

**Definition.** Environmental monitoring is both:

- A. Systematic verification of the implementation of mitigation measures.
- B. Systematic observation of key environmental conditions.

Environmental monitoring is a necessary complement to mitigation. Its purpose is to tell us clearly and cost-effectively if mitigation is sufficient and effective.

Throughout this session, we will see that environmental monitoring must be highly targeted.

**A.** Verifying Implementation of Mitigation Measures. We can verify (and quantify!) implementation of mitigation measures in two ways: via paper reports and via field inspection. In each case, we use **mitigation implementation indicators**. For example, monitoring of medical waste management in a clinics activity

could ask the beneficiary clinics to attach their waste management plan. A field inspection would spot check that key elements of the plan were being implemented.

Good environmental monitoring is targeted and takes the simplest effective approach. It usually requires a combination of environmental conditions indicators and mitigation implementation indicators.

#### **B.** Observing environmental conditions. The environmental conditions observed are those:

- That correspond to impacts and mitigation measures. For example, a key potential impact of an irrigation project is groundwater contamination. Therefore, **ground-water quality** is monitored.
- Upon which the project depends for its success. For example, a water supply project depends on clean source water. Therefore, **source water quality** is monitored.

We observe and measure environmental conditions by using **environmental indicators**, which are signals of or proxies for the stock and quality of key environmental resources, or of environmental health and ecosystem function.

Indicators can require complex equipment to measure (e.g. testing water for pesticide residues), but they can also be very simple—and often for small-scale activities simple indicators are best. (For example, groundwater levels can be measured in a shallow well using a rope and bucket.)

A key principle of monitoring is choosing the simplest indicator that meets your needs.

#### NOTE: environmental indicators are NOT "F" indicators or core program performance indicators.

To distinguish the impacts of your activity from other factors, thought needs to go into the times and places that indicators are measured.

For example, consider an agricultural processing facility that draws water from a stream. The facility has potential to adversely impact surface water quality. A good monitoring approach would:

- Take water samples from the stream at the intake point and downstream from the seepage pits.
- Take samples from these different locations at the same time.
- Take samples during both high and low flow periods during the processing season.

What is the relationship of monitoring to environmental compliance? Initial Environmental Examination and Environmental Assessment conditions are <u>mitigation</u> requirements. IEEs (and EAs) are useless unless the conditions they establish are implemented! USAID's environmental procedures therefore <u>require</u> implementation of IEE/EA conditions (mitigation) and <u>monitoring</u> this implementation.

#### Part 2. Environmental Mitigation and Monitoring Plans (EMMPs)

**The need.** Across USAID, implementation of IEE and EA conditions is the weakest element of life-of-project environmental compliance.

A key lesson learned from 40 years of EIA experience world-wide is that it is almost impossible to systematically carry out the mitigation measures that result from the EIA process unless an EMMP exists, and is incorporated into a project's workplan and budget.

**The concept.** Environmental Mitigation and Monitoring Plans (EMMPs) are a framework for specifying and organizing mitigation and monitoring, and assuring that it responds systematically to IEE/EA conditions.

In their most basic form, EMMPs are a simple table that sets out:

ALL the mitigation measures being implemented in response to IEE/EA conditions

- The monitoring that will determine whether the mitigation is sufficient and effective.
- Who is responsible for both mitigation & monitoring...

EMMPs may also include **budgeting** information for mitigation and monitoring and a **monitoring log section where** monitoring results can be recorded. We illustrate the EMMP concept at the end of the *session with an extended example*.

(Note that EMMPs are also known as EMPs (Environmental Management Plans), EMPRs (Environmental Mitigation Plan and Report), and similar acronyms. EMMP is the most widely used term. EMMP formats likewise vary. IEEs or awards sometimes specify an EMMP format, but more often in AFR the IP has flexibility in designing/adopting/adapting a format that meets the needs of the particular project. The formats used in this workshop are the most common and are acceptable in most contexts.)

**AFR IEEs requiring EMMPs.** USAID's environmental procedures require that environmental mitigation required by IEEs and EAs is implemented and monitored, but do not require EMMPs *per se*. However, almost all new AFR IEEs (and those in other regions as well) require that EMMPs be developed and implemented.

This requirement can be operationalized either as technical direction from the C/AOR or as a provision of new contracts and agreements.

(Title II Cooperating Sponsors are required to develop EMMPs by the Agency's DFAP guidance.)

**EMMP submission and approval.** EMMPs should be approved by the C/AOR; sometimes there is additional review by the MEO or REA. C/AORs should require that they are submitted together with the project's workplan or PMP.

## Part 3. Translating IEE Conditions to Mitigation Actions

IEE conditions are often written very generally. For example, an IEE might specify that "wells shall be sited to minimize the possibility of contamination." (Or even more generally: wells shall be sited and constructed consistent with good practices.")

Implementing this IEE condition (which begins with developing an EMMP) requires that it be translated into specific mitigation actions.

In this case, the project would need to develop or adopt a set of specifications for well location that can then be referenced in the EMMP.

For example, the project might adopt the following, based on the Sector Environmental Guidelines:

The following MINIMUM distances from potential sources of contamination will be observed for well siting:

- 150 ft (45.7 m) from a preparation area or storage area of spray materials, commercial fertilizers, or chemicals that may cause contamination of the soil or groundwater.
- 100 ft. (30.5 m) from a below-grade manure storage area.
- 75 ft (22.9 m) from cesspools, leaching pits, and dry wells.
- 50 ft (15.2 m) from a buried sewer, septic tank, subsurface disposal field, grave animal or poultry yard or building, privy, or other contaminants that may drain into the soil.
- The distance between a septic tank leach field and a down-gradient well should be greater than 100 ft (30.5 m) if

#### the soil is coarser than fine sand and the groundwater flow rate is greater than 0.03 ft/day (0.01 m/day).<sup>2</sup>

The EMMP could then list the concrete mitigation action as "compliance with project well siting criteria," and attach those criteria as an Annex.

In this session, we will work in groups through a set of actual examples of "general IEE conditions" and discuss how to translate them into specific mitigation actions.

#### Part 4: EMMP-based IP Environmental Compliance Reporting

ADS 204 requires that C/AORs monitor and evaluate <u>on an ongoing basis</u> whether the environmental mitigation required by the governing IEE(s)/EA is being implemented and is effective. (In other words, C/AOR oversight responsibilities extend to environmental compliance, just as they do to other elements of project implementation.)

Practically, this requires that IPs not only systematically comply with IEE/EA conditions by developing and implementing EMMPs, but that they *report* to USAID on this implementation.

IP environmental compliance reporting consists of two elements—one required and one recommended:

## 1. Project reporting must provide an auditable record of environmental compliance.

Generally, IPs' quarterly or semiannual reports should contain a separate environmental compliance section. The section must provide sufficient information on the status of EMMP implementation for USAID to effectively fulfill its oversight and performance monitoring role.

If the EMMP contains a "monitoring log" section, then the EMMP itself, updated with current monitoring results, can simply be appended to the report.

For large projects with complicated EMMPs, a text summary/short analysis of EMMP implementation is needed. This should highlight key mitigation activities underway in the reporting period, any significant issues encountered, and corrective actions/adjustments made.

Any specific reporting requirements imposed by the IEE or EA must also be satisfied.

# 2. Strongly recommended: One or more key project performance indicator(s) (project results frame work) reflect overall environmental soundness/environmental compliance.

In other words, the most critical elements of environmental soundness/ compliance should be "mainstreamed" into the project results framework. For example:

*In a water point provision project*, the IP might use the indicator "number of <u>protected</u> water points established with <u>zero fecal coliform</u> <u>after 6 months</u>" rather than "number of water points established."

*In a road rehabilitation project*, the IP might use the indicator "km or road rehabilitated <u>under</u> environmentally sound practices" rather than "km of road rehabilitated."

In both cases, the "environmentalized indicator" demonstrates the core project activities are being executed with attention to environmental soundness/compliance. It is NOT expected or appropriate to "environmentalize" every key indicator, or to capture every mitigation measure.

(This best practice applies to new awards. Where EMMPs are developed after the PMP is established, it may not be possible to change key performance indicators.)

<sup>&</sup>lt;sup>2</sup> Source: Driscoll, Groundwater and Wells, Second Edition, as cited in the Small Scale Guidelines.

Missions should not rely on IP progress reports alone to track environmental compliance. Field visits at minimum should include a quick check for significant environmental design/management problems (for small-scale wat/san, health care, construction, or rural roads activities, use the *Visual Field Guides*). For environmentally complex activities, specific field visits should be made to verify EMMP implementation.

# **Key resource**

The Sector Environmental Guidelines are a key resource for design of mitigation and monitoring measures. The EMMP Factsheet is included as an annex to this sourcebook. It includes formats and how-to guidance.